

Sill Cover Replacement Instructions


800.334.2006

8817 West Market Street
Colfax, NC 27235

Endura[®]
PERFORMANCE STANDARD

1 Measure Sill

Measure distance between jamb stops.



2 Cut Sill Cover to Fit

Cut sill cover length 1/8" less than measurement.



3 Attach Cover to Sill

- Hook front edge of sill cover into sill extender cavity.
- Rotate cover over sill interior edge.
- Press center leg into gap between sill cap and nosing.



4 Sill Cover Final Positions

Proper Sill Cover Positioning: Z-Series Sills

